



Made in Estonia, EU

製造元:

HUUM OÜ

Vahi tee 9, Tartumaa
60534, Estonia

販売元:

HUUMジャパン合同会社

info@huum.jp

huum.jp

#huumsauna

EN Heat Exchanger

- The HUUM HEAT/WOOD heater must be in place to install the Heat exchanger. Also, make sure there aren't any stones placed in the heater.
- Place the Heat exchanger on the side of your choice (back side or sides edges).
- The Heat exchanger must sit on a triangular angle, firmly against the heater.
- When connecting the Heat exchanger to the water and filling the heater with stones, make sure that the Heat exchanger fits snugly against the stove.
- The Heat exchanger works only if the water tank is placed higher than the Heat exchanger pipe connections. Minimum diameter of the water pipe is 3/4". The inclination of the pipe must prevent the air bubbles to get stuck in circulation.
- The purchase receipt gives the product a warranty of 24 months. Warranty applies to a defective product and does not apply to wear and rust caused by natural use.

Find the latest updates on our website www.huum.jp

JP 熱交換器 (ヒートエクスチェンジャー)

- 熱交換器を設置する前にHUUMサウナストーブをサウナルームに設置する必要があります。また熱交換器取り付け時にサウナストーンがストーブ本体に残ってないことを確認してください。
- ストーブ本体の背面もしくは側面に設置することが出来ます。
- 熱交換器は、三角形にしっかりとはまるように配置します。
- 熱交換器を給水配管に接続し、ヒーターに石を敷き詰めたら、熱交換器がストーブににびったりと配置されていることを確認します。
- 熱交換器は、給水タンクが熱交換器配管接続部より上に配置されている場合にのみ作動します。給水配管の最小直径は3/4です。配管は、気泡が循環を滞らせないように傾斜させなければなりません。
- お買い上げの際の領収書が、24ヶ月間の製品保証書となります。保証は製品の欠陥に対してのみ適用されるものであり、通常の使用において生じる錆や摩耗は対象となりません。

最新の情報については、以下の当社ウェブサイトをご覧ください。
www.huum.jp